



## Bytes Back Data Recovery

891A Graham Road  
Cuyahoga Falls, OH 44221  
(234) 525-3687

[www.BytesBackDataRecovery.com](http://www.BytesBackDataRecovery.com)  
datarecovery@pakcomputers.com



Assembly Instructions



figure 1



figure 2



figure 3

1. Select the correct box for your hard drive. The boxes are labeled near one of the barcodes as either AD#1 for 3.5" drives or AD#2 for 2.5" drives.
2. Take the 4 long and narrow ends and fold them at the perforations.
3. After folding the first 2 tabs, your box should resemble figure 1.
4. Fold the remaining 2 tabs.
5. Place hard drive inside an anti-static bag.
6. Insert your hard drive into the precut notches one side at a time.
7. Your drive should now be secured in place as shown in figure 2.
8. While holding the drive in place fold down the remaining 2 round flaps over the top of the drive.
9. Insert the small tabs into the slots as shown in figure 3.

**\*NOTE BEFORE SEALING BOX:**

Please be sure to include the Drive Analysis Form with all information filled out.